

LIGHTING

HMI LIGHTING

Spare Globes are included with each lamp order. The renter will be charged for any broken globe or any spare or burn-out not returned to Day – 1. All 120v lamps larger then 2K are supplied with Bates -style 3-pin, grounded connectors. Prices are Flat Rate, no bulb-hours are charged.

FRESNEL

ITEM.....	DAILY
18K HMI Fresnel (stand not included)	830.00
12K HMI Fresnel (stand not included)	530.00
1.2K HMI Fresnel	135.00
575w HMI Fresnel	115.00

Includes: Lamp Head, Ballast, Globe, Spare Globe, Barn Doors (except 18K/12K), 5 Piece Scrim Set, Gel Frame and Stand.
18K/12K may require Crank-up Stand.

PAR

ITEM	DAILY
12K HMI CinePar (stand not included)	880.00
6K Arrilite (stand not included).....	750.00
4K HMI CinePar	490.00
2.5K HMI CinePar	275.00
1.2K HMI CinePar	160.00
575w HMI CinePar	135.00
200w HMI CinePar	145.00

Includes: Lamp Head, Ballast, Globe, Spare Globe, Barn Doors , Lens Set W/Box, 3-Piece Scrim Set and Stand.
6K and 4K CinePar may require Crank-up Stand

FLICKER FREE BALLAST

ITEM	DAILY
18K HMI	230.00
12K HMI.....	230.00
6K HMI	150.00
4K HMI	115.00
2.5K HMI	115.00
1.2K/575W HMI	105.00

HEAD EXTENSION

ITEM	DAILY
18K HMI Head Extension	35.00
12K HMI Head Extension	30.00
6K HMI Head Extension	23.00
4K/2.5K HMI Head Extension	18.00
1.2K/575 HMI Head Extension	18.00
200w HMI Head Extension	12.50

CRANK-UP STANDS

ITEM	DAILY
Super Crank-O-Vator Stand.....	58.00
Crank-O-Vator Stand	46.00
Cine Vator Stand	65.00
Low Crank-O-Vator Stand	58.00